

SELECTION CHART



To determine the correct **SUPER-SCREW® Evolution**, screws and skiving blades, select the characteristics of your belt within the chart below.

For belts ranging from **EP250** to **EP630** (from **200 PIW** to **360 PIW**), refer to the **SUPER-SCREW® Evolution** range below. For EP or PP belts above **630 N/mm** (**360 PIW**), please refer to the **SUPER-SCREW®** range.



Template can be used with EP or PP (PN or NN) multiply belt


3 STEPS


to choose your SUPER-SCREW® Evolution

- Choose your SUPER-SCREW® from the Evolution range
- Depending on your belt construction (EP or PP belt column) determine which SUPER-SCREW® Evolution to use.
- Select your screw size
- Once your SUPER-SCREW® EVOLUTION has been selected, identify the required screw size depending on your belt thickness.
- Select your skiving blades
- Depending on your belt thickness before skiving, easily determine which blades to use to skive.



SUPER-SCREW® Evolution required length for your belt





Metric values	SIDE A (mm)	Number of screws	Number of spacers	SIDE A (mm)	Number of screws	Number of spacers	
Belt width (mm)	SUPER-	SCREW® Evolutior	ı 35 - 40	SUPER-SCREW® Evolution 63 - 65			
500	517	46	2	517	92	2	
600	630	56	3	630	112	3	
650	675	60	3	675	120	3	
800	832	74	3	832	148	3	
900	945	84	4	945	168	4	
1000	1035	92	4	1035	184	4	
1200	1260	112	4	1260	224	4	
1300	1350	120	5	1350	240	5	
1400	1462	130	5	1462	260	5	
1500	1575	140	5	1575	280	5	
1600	1665	148	6	1665	296	6	
1800	1890	168	6	1890	336	6	
2000	2092	186	7	2092	372	7	

Imperial values	SIDE A (inch)	Number of screws	Number of spacers	SIDE A (inch)	Number of screws	Number of spacers	
Belt width (inch)	SUPER-	SCREW® Evolution	ı 35 - 40	SUPER-SCREW® Evolution 63 - 65			
18	18 3/4	46	2	18 3/4	92	2	
24	24 ^{3/4}	56	3	24 ^{3/4}	112	3	
30	31 3/4	60	3	31 3/4	120 148	3	
36	38	74	3	38			
42	44 1/4	92	4 44 1/4		184	4	
48	50 1/2	120	5	50 ^{1/2} 56 ^{3/4}	240 280	5	
54	56 ^{3/4}	140	5			5	
60	62 ^{3/4}	168	6	62 3/4	336	6	
72	75	186	7	75	372	7	

PACKAGING

In kit or roll, depending on your needs

READY-TO-USE KIT (CUT LENGTHS)

depending on your belt type and width (available in some grades and models of SUPER-SCREW® Evolution).



The ready-to-use kit contains:

- SUPER-SCREW® Evolution, cut to length, pre-assembled by MLT (complete with spacers),
- screws,
- PZ bit.
- installation kit:
 - SUPER-SCREW® Evolution installation method,
 - installation templates,
 - installation tool.

BULK ROLLS

(available in some grades and models of SUPER-SCREW® Evolution).



The roll includes:

- rolls of SUPER-SCREW® Evolution (upper part + lower part) to assemble yourself (screws to be ordered separately),
- spacers,
- PZ bits,
- installation kit
 - SUPER-SCREW® Evolution installation method,
 - installation template,
 - installation tool.

SUPER-SCREW® Evolution 35 to 65 are available in rolls of 3, 5, 10 and 25 meters with stainless steel or steel inserts depending on the range.

Technical data

Metric	SUPER-SCREW® Evolution						
Metric	35	40	63	65			
Maximum belt tension, N/mm	315	400	630	630			
Min pulley Ø, mm	160	180	200	230			
Thickness top cover, mm	3.5	3.5	4	6			
Thickness bottom cover, mm	3	3	3	3			

Imperial	SUPER-SCREW® Evolution						
imperiat	35	40	63	65			
Maximum belt tension, PIW	200	230	360	360			
Min pulley Ø, inch	6	7	8	9			
Thickness top cover, inch	9/64	9/64	5/32	1/4			
Thickness bottom cover, inch	1/8	1/8	1/8	1/8			

Quantity required

	SUPER-SCREW® Evolution 35 - 40			SUPER-SCREW® Evolution 63 - 65						
	1 m	3 m roll	5 m roll	10 m roll	25 m roll	1 m	3 m roll	5 m roll	10 m roll	25 m roll
Screws	92	276	460	920	2300	184	552	920	1840	4600
Spacers	4	12	20	40	100	4	12	20	40	100
PZ2 bits	1	1	1	2	2	1	1	1	2	2





